

APPLY OFS



APPLY OFS AND LET CHOP ACCUMULATE. IT IS MOST EFFECTIVE WHEN TAPED TO THE FLOOR USING DUCT TAPE. WHEN OFS IS ADHERED STRONGLY TO THE FLOOR IT LASTS LONGER AND PROVIDES A SAFER WORK ENVIRONMENT FOR TECHS.

SCRAPE AN EDGE

ONCE ACCUMULATION REACHES YOUR POINT OF REMOVAL USE AN ICE SCRAPER OR SHOVEL TO CREATE AN EDGE. THIS CAN BE DONE BY HAND BUT THE LARGER THE CHUNK IS TO START - THE EASIER THE MATRIX IS TO REMOVE.



BEGIN YOUR PEEL



ONCE AN EDGE HAS BEEN CREATED PEEL UP MATRIX BY HAND AND DISPOSE. THIS CAN BE DONE REPEATEDLY UNTIL THE MATERIAL BEGINS TO BREAK DOWN AND TEAR. JUST DISPOSE OF THE FIBERGLASS CHOP AND RESIN LEFT BEHIND.

